

Figure: 30 TAC §115.435(a)(8)(B)(ii)

$$CE = \frac{(L - F)}{L}$$

Where:

CE = The capture efficiency, decimal fraction.

L = The mass of liquid volatile organic compounds (VOC) input to process (use Procedure L).

F = The mass of fugitive VOC that escapes from a temporary total enclosure (TTE) (use Procedure F.1).