

Figure: 30 TAC §115.455(a)(4)(B)(iv)

$$CE = \frac{L}{F_B - L}$$

Where:

CE = The capture efficiency, decimal fraction.

L = The mass of liquid volatile organic compounds (VOC) input to process (use Procedure L).

F<sub>B</sub> = The mass of fugitive VOC that escapes from building or room enclosure (use Procedure F.2).